

Base Assembly Instructions

For the U333 & U338 Series

Step 1

Attach the rotating base (08) to the top of the two cross legs (02 & 05) with the four M8*30 Alan head bolts (06). (M8 wrench included)

Step 2

Attach the H-style support channel (10) to the top of the rotating base with the four M8*20 Alan head bolts (09).

STEP 3

Remove the thumbscrew knob (14) and the gasket (13). Slide the base cover (11) down over the H-style support channel.

Step 4

Slide the gasket down the H-channel and position it on the lower post sleeve.

Step 5

Loosen the four M8*30 screws (130) located at the bottom of the main post. Slide the main frame over the H-channel.

Step 6

Insert and tighten the thumbscrew knob then re-tighten the four M8*30 screws at the bottom of the main post.

CAUTION:

When removing the main frame from the base, make sure to loosen the four M8*30 screws and remove the thumbscrew knob before lifting the umbrella from the base.

