

Guide for Replacing the Rope Lights

Warning: Always unplug any electrical appliance before attempting any repairs.

STEP 1

Remove the fabric from the umbrella. Lay the umbrella on it side over table or workbench. Disconnect the rib from the rib connector.

STEP 2

Remove the electric box cover. Locate the two wires from the rope light being replaced. Disconnect the WHITE and RED wire from the terminals.

STEP 3

Attach a 3' piece of fishing line to the wires before removing the rope light. This will help in pulling the new wires back into the electric box. Remove the light from the rib frame and then carefully pull the rope light from the electrical box.

STEP 4

Attach the fishing line to the new wires and carefully pull the wires into the electric box then place the rope light back into the rib frame.

STEP 5

Connect the new wires to the appropriate terminals.
Note: check to make sure all wire connections in the electric box are properly tightened.

STEP 6

Reattach the cover to the electric box and return the umbrella to an upright position. Reconnect the transformer to the 110V outlet and to the umbrella to test the light system. If satisfied, then place the fabric back onto the umbrella. You have completed the repair.

For further assistance contact our service @ Wandatech.com